TravelMate 5730 Series

Quick Guide

Copyright © 2008. Acer Incorporated. All Rights Reserved. Travelmate 5730 Series Quick Guide Original Issue: 05/2008 Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose. Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number and purchase information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated. TravelMate 5730 Series Notebook PC Model number: _____

Acer and the Acer logo are registered trademarks of Acer Incorporated. Other companies' product names or trademarks are used herein for identification purposes only and belong to their respective companies.

Serial number: ___

Place of purchase: _____

Federal Communications Commission Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The following local manufacturer/importer is responsible for this declaration:

Product name: Notebook PC

Model number: MS2231

Machine type: TravelMate 5730

SKU number: TravelMate 5730-xxxxx ("x" = 0 - 9, a - z, or A - Z)

Name of responsible party: Acer America Corporation

Address of responsible party: 333 West San Carlos St. San Jose, CA 95110 USA

Contact person: Acer Representative

Tel: 1-254-298-4000

Fax: 1-254-298-4147

CE Declaration of Conformity



We,

Acer Computer (Shanghai) Limited 3F, No. 168 Xizang medium road, Huangpu District, Shanghai. China

Contact Person: Mr. Easy Lai

Tel: 886-2-8691-3089, Fax: 886-2-8691-3000

E-mail: easy_lai@acer.com.tw

Hereby declare that:

Product: Notebook PC Trade Name: Acer

Model Number:MS2231 Machine Type: TravelMate 5730

SKU Number: TravelMate 5730-xxxxx ("x" = $0 \sim 9$, a \sim z, or A \sim Z)

Is compliant with the essential requirements and other relevant provisions of the following EC directives, and that all the necessary steps have been taken and are in force to assure that production units of the same product will continue comply with the requirements.

EMC Directive 2004/108/EC as attested by conformity with the following harmonized standards:

- EN55022:1998 + A1:2000 + A2:2003, AS/NZS CISPR22:2002, Class B
- EN55024:1998 + A1:2001 + A2:2003
- EN55013:2001 + A1:2003 + A2:2005 (Applied to product with TV function)
- EN55020:2007 (Applied to product with TV function)
- EN61000-3-2:2000 + A2:2005, Class D
- EN61000-3-3:1995 + A1:2001 + A2:2005

Low Voltage Directive 2006/95/EC as attested by conformity with the following harmonized standard:

- EN60950-1:2001 + A11:2004
- EN60065:2002 (Applied to product with TV function)

Council Decision 98/482/EC (CTR21) for pan- European single terminal connection to the Public Switched Telephone Network (PSTN).

RoHS Directive 2002/95/EC on the Restriction of the Use of certain Hazardous Substances in Electrical and Electronic Equipment.

R&TTE Directive 1999/5/EC as attested by conformity with the followingharmonized standard:

- Article 3.1(a) Health and Safety
 - EN60950-1:2001+ A11:2004
 - EN50371:2002

- Article 3.1(b) EMC
 - EN301 489-1 V1.4.1
 - EN301 489-3 V1.4.1
 - EN301 489-17 V1.2.1
- Article 3.2 Spectrum Usages
 - EN300 220-3 V1.1.1
 - EN300 328 V1.6.1
 - EN300 440-2 V1.1.2
 - EN301 893 V1.2.3

CE Issued Date: 29 February 2008

Easy Lai

Easy Lai / Director

Acer Computer (Shanghai) Limited

29 Feb 2008

Date

First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.

Your guides

To help you use your Acer notebook, we have designed a set of guides:

First off, the Just for Starters...poster helps you get started with setting up your computer.

The printed **TravelMate Series Generic User Guide** contains useful information applying to all models in the TravelMate product series. It covers basic topics such as Acer's Empowering Technology, using the keyboard, Audio, etc. Please understand that due to its nature, the Generic User Guide as well as the AcerSystem User Guide mentioned below will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The printed **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the AcerSystem User Guide. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

1 Click on Start, All Programs, AcerSystem.

2 Click on AcerSystem User Guide.



Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on AcerSystem User **Guide** will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the Help and Support menu.

Your Acer notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new Acer notebook.


Top view



#	Item	Description
1	Acer Crystal Eye	Web camera for video communication (only for certain models).


#	Item	Description
2	Acer PureZone	Two internal stereo microphones for sound recording.
3	Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
4	Speakers	Left and right speakers deliver stereo audio output.
5	Empowering key	Launch Acer Empowering Technology
6	Productivity keys	Three productivity keys give users one-touch access to protection and manageability features for a more secure, smarter and easier way to work. Please refer to "Generic User Guide" for more details.
7	Easy-launch buttons	Buttons for launching frequently used programs. Please refer to "Generic User Guide" for more details.
8	Palmrest	Comfortable support area for your hands when you use the computer.
9	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
10	Click buttons (left, center* and right)	The left and right buttons function like the left and right mouse buttons.
		*The center button serves as Acer BioProtect fingerprint reader supporting Acer FingerNav 4-way control function (manufacturing option).
11	Acer Bio-Protection fingerprint reader	The center button serves as Acer Bio-Protection fingerprint reader supporting Acer FingerNav 4-way control function (only for certain models).
12/15	Status indicators	Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components. Please refer to "Generic User Guide" for more details.
13	Keyboard	For entering data into your computer.
14	Power button	Turns the computer on and off.

Closed front view



#	lcon	Item	Description
1		Latch	Locks and releases the lid.
2	MULTIMODAL AND	5-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick Pro (MS PRO), and xD- Picture Card.
	XD		Note: Only one card can operate at any given time.
3	(+ +)	Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman, mp3 player)
4	Ley	Microphone jack	Accepts inputs from external microphones.
5	ಣ	Headphones/ speaker/line-out jack.	Connects to audio line-out devices (e.g., speakers, headphones).
6	*	Bluetooth communication switch	Enable/disable the Bluetooth function.
7	C	Wireless communication switch	Enable/disable the wireless function.

Left view



#	Icon	Item	Description
1	ĸ	Kensington lock slot	Connects to a Kensington-compatible computer security lock.
2	0	Acer EasyPort IV connector	Connects to Acer EasyPort IV.
3		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
4	윰	Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.
5	номі	HDMI port	Supports high definition digital video connections.
6	•<*	Two USB 2.0 ports	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
7		PC Card slot	Accepts one Type II PC Card.
8	ExpressCard / 54	ExpressCard/54 slot	Accepts one ExpressCard/54 module.
9		PC Card slot eject button	Ejects the PC Card from the slot.

Right view




#	Item	Description
1	Optical drive	Internal optical drive; accepts CDs or DVDs.
2	Optical disk access indicator	Lights up when the optical drive is active.
3	Optical drive eject button	Ejects the optical disk from the drive.
4	Emergency eject hole	Ejects the optical drive tray when the computer is turned off. Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.

Rear view



#	lcon	Item	Description
1	● ✓•+	USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).
2	← / e SATA	USB 2.0/ e SATA port	Connects to USB 2.0 or eSATA devices. Note: If you plug an eSATA device you will have three USB ports available in the mean time.
3		Modem (RJ-11) port	Connects to a phone line.
4	===	DC-in jack	Connects to an AC adapter.
5		Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Base view



#	lcon	Item	Description
1		Hard disk bay	Houses the computer's hard disk (secured with screws)
2		Acer DASP (Disk Anti- Shock Protection)	Protects the hard disk drive from shocks and bumps.
3		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening of the fan.
4		Memory compartment	Houses the computer's main memory.
5		Battery lock	Locks the battery in position.
6		Battery release latch	Releases the battery to remove the battery pack.
7	₫	Battery bay	Houses the computer's battery pack.

Specifications

•		
Operating system	 Windows Vista[™] 	
Platform	• Intel [®] Centrino [®] 2 processor technology, featuring	:
	 Intel[®] Core[™] 2 Duo mobile processor 	
	 Mobile Intel[®] GM45/PM45 Express Chipset* 	
	 Intel[®] Wireless WiFi Link 5100/5300 	
System memory	Dual-Channel DDR2 support	
	 Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules* 	e
Display	• 15.4" WXGA 1280 x 800	
Graphics	Mobile Intel® GM45 Express Chipset*	
	ATI Mobility Radeon [™] HD 3470*	
	NVIDIA® GeForce® 9300M GS*	
Storage	• 2.5" hard disk drive	
subsystem	Optical drive options:	
	 Blu-ray Disc[™]/DVD-Super Multi double-layer 	
	driveDVD-Super Multi double-layer drive	
	DVD-super Mutti double-layer drive DVD/CD-RW combo drive	
	• 5-in-1 card reader	
Audio	Two built-in Acer 3DSonic stereo speakers	
	High-definition audio support	
	MS-Sound compatibleAcer PureZone technolgy with two built-in stereo	
	microphones	
	Built-in microphone	
Communication	Acer Video Conference, featuring:	
	Integrated Acer Crystal Eye webcam*	
	 Optional Acer Xpress VoIP phone WLAN: Intel[®] Wireless WiFi Link 5100/5300 	
	WPAN: Bluetooth® 2.0+EDR	
	LAN: Gigabit Ethernet, Wake-on-LAN ready	
	Modem: 56K ITU V.92	
Privacy control	• Enhanced Acer DASP (Disk Anti-Shock Protection)	
	Acer Bio-Protection fingerprint solution* BIOS programmed ALDD programmed	
	BIOS user, supervisor, HDD passwordsKensington lock slot	
Dimensions	• 360 (W) x 267 (D) x 30.3/43 (H) mm	
5	(14.17 x 10.51 x 1.09/1.69 inches)	
	• 3.02 kg (6.64 lbs)*	
	• 2.88 kg (6.34 lbs)*	

	A CRI D O
Power	• ACPI 3.0
subsystem	• 71 W 4800 mAh
	• 44.4W 4000 mAh
	• 3-pin 65/90 W AC adapter
	 Engergy Srat 4.0
Input devices	88-/89-key keyboard
I/O interface	Acer EasyPort IV connector
	 ExpressCard[™]/54 slot
	PC Card slot (Type II)
	Acer Bio-Protection fingerprint reader*
	 5-in-1 card reader (SD[™], MMC, MS, MS PRO, xD)
	 HDMI[™] port with HDCP support
	Three USB 2.0 ports
	USB 2.0/ eSATA port
	(3)
	Note: If you plug an eSATA device you will have three USB ports available in the mean time.
	 External display (VGA) port
	Headphone/speaker/line-out jack
	Microphone-in jack
	Line-in jack
	Ethernet (RJ-45) port
	Modem (RJ-11) port
	DC-in jack for AC adapter
Environment	Temperature:
	Operating: 5 °C to 35 °C
	 Non-operating: -20 °C to 65 °C
	 Humidity (non-condensing):
	 Operating: 20% to 80%
	Non-operating: 20% to 80%



Note: "*" "only for certain models".



Note: The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.